



PR98A01P – 911 front shock absorber bushings installation instructions



<u>Parts needed:</u>	<u>Tools required:</u>
✓ PR98A01P – 911 front shock absorber bushings (1969-89) SET (2 pcs - only rubber, no housing)	✓ Hydraulic press

Difficulty level:



Procedure:**Old bushings removal:**

1. Remove all the hardware (bolts, washers, pressure plates) from the support mount housing if attached:



2. Use the hydraulic press to remove old bushings from both support mount housings.



3. Once old bushings are removed from the support mount housing clean all the parts.



OPTIONALLY you can renew all the parts: sandblasting and yellow zinc plating

Bushing installation:

4. Install new bushing into the the support mount housing.
Bushing consists of two parts (top and bottom part) with different diameters. Install bushing (bottom part with larger diameter) to the bottom part of the support mount housing oriented as shown on the picture. Also make sure the bushing seats nicely in the support mount housing.



5. Install the top bushing part (smaller diameter) from the upper side of support mount housing oriented as shown on the picture:



6. Press the bushing with hydraulic press to seat firmly in the metal housing:





7. Repeat steps 4-6 to press in the second bushing to the other support mount housing.



8. Install pressure plates, washers and bolts.



Thank you for your purchase!



www.prekom-usa.com

www.prekom.si

