

FITTING INSTRUCTIONS - Ferrari 360, 430, 575, 612 (rear/front axle)

KIT FR65002P includes:

- **Tool FR65002P - A**
(top piece)



- **Tool FR65002P - B**
(bottom piece)



Assembling the top silent block into the wishbone

PLEASE NOTE: The surface of the pressed silent block, should be oiled, to make pressing easier.

➤ **Phase 1**

- Place tool A on one side of the silent block. Turn tool A with the arrow pointing towards the silent block.



➤ **Phase 2**

- Place the wishbone on tool B. Turn tool B with the arrow pointing up. The wishbone should be in line with the centre of the tool.



➤ **Phase 3**

- Carefully press the silent block into the wishbone.




- The silent block's edge should lean on the wishbone perfectly.



➤ **Phase 4**

- Repeat the same assembling process (Phase 1-4) with the second silent block.



CONGRATULATIONS, you have done it!